



Vendor: CompTIA

Exam Code: PD0-001

Exam Name: CompTIA PDI+ Exam

Version: DEMO

QUESTION 1

Which of the following functions is associated with the developer unit?

- A. Supplies toner to the photoconductor
- B. Charges the surface of the photoconductor
- C. Writes the latent image on the photoconductor
- D. Cleans the photoconductor

Answer: A

QUESTION 2

An encoder sensor typically detects:

- A. paper position.
- B. shaft rotation.
- C. magnetic flux.
- D. laser beam strength.

Answer: B

QUESTION 3

The customer has a dedicated ink jet fax machine that is used to send and receive faxes only from the corporate office. The user complains of streaks on the received faxes while the internal self-prints are fine.

Which of the following should a technician recommend?

- A. Clean the scanner glass on the distant machine.
- B. Clean the scanner glass on the local machine.
- C. Clean the printer head on the local machine.
- D. Call the telephone company to increase the line signal level.

Answer: A

QUESTION 4

Which of the following stages in the laser print process attracts toner to the latent image on the photoconductor?

- A. Writing
- B. Fusing
- C. Development
- D. Transfer

Answer: C

QUESTION 5

Which of the following would be the BEST process for the technician to follow when beginning diagnose a unit at a customer's site? to

- A. Check the printers error log, and then inform the primary user what the issue is.

- B. Go directly to the printer and investigate any issues that are found.
- C. Investigate the printers status, then ask the primary user to write down what they think is wrong.
- D. Gather information from the primary user, and then evaluate the printers condition.

Answer: D

QUESTION 6

Which of the following utilities could be used to determine a subnet mask?

- A. PING
- B. NSLOOKUP
- C. TRACERT
- D. IPCONFIG

Answer: D

QUESTION 7

How many CCDs are located in a single pass duplex ADF?

- A. One
- B. 2
- C. 3
- D. 4

Answer: B

QUESTION 8

When is it advisable to dump the waste toner from a technicians service vacuum?

- A. When it is full.
- B. It is not recommended.
- C. Before performing preventative maintenance.
- D. After each call.

Answer: B

QUESTION 9

A customer has installed a new computer on their network. They can print to the printer but the option for duplex printing is not available. All other computers have the option. Which of the following is the cause of the problem?

- A. The new computer is printing to the wrong IP address.
- B. The new computer is using the wrong protocol.
- C. The driver port is not setup correctly.
- D. The option has not been selected on the driver.

Answer: D

QUESTION 10

A polygon mirror is part of which of the following assemblies?

- A. Laser unit
- B. Developer unit
- C. Charge assembly
- D. Fuser assembly

Answer: A

QUESTION 11

In which of the following sections of an MFP would a technician find a Xenon Lamp?

- A. The paper feed section
- B. The fuser section
- C. The scanner section
- D. The transfer section

Answer: C

QUESTION 12

During the photoconductor preparation step, residual charge can be removed by which of the following? (Select TWO).

- A. Pressure
- B. Oil
- C. Light
- D. Gravity
- E. Electrical Charge

Answer: CE

QUESTION 13

Which of the following components is part of the ink dispersion system?

- A. Print Heads
- B. Cleaning heads
- C. Pickup Roller
- D. Charge Assembly

Answer: A

QUESTION 14

The proper safety guidelines for handling any device specific consumables can be found in which of the following documentation?

- A. Material Safety Data Sheets
- B. Installation Guides
- C. Consumer Reports

D. Devices Parts Catalog

Answer: A

QUESTION 15

A customer is concerned about excessive media jamming in their device. Which of the following is the FIRST thing a technician should check?

- A. Media feed rollers
- B. Cassette drawers
- C. Fusing section
- D. Device log data

Answer: D

QUESTION 16

The polygon mirror is located in which of the following components?

- A. Developer unit
- B. Scanner unit
- C. Fuser unit
- D. Laser unit

Answer: D

QUESTION 17

Which of the following is the purpose of a torque limiter in a roller?

- A. To reduce wear and tear on rollers.
- B. To provide resistance but still allow some slippage.
- C. To limit the amount of movement by media.
- D. To make it easier to replace rollers.

Answer: B

QUESTION 18

Using the CMYK color model, the color purple is produced by combining cyan and which other color?

- A. Green
- B. Magenta
- C. Yellow
- D. Black

Answer: B

QUESTION 19

Which of the following is a reason black toner is used in color printers?

- A. It decreases the print speed in color laser printers.
- B. It prevents moir patterns when printing color photographs.
- C. It reduces the cost per page when printing gray scale documents.
- D. It makes the color toner resistant to smudging when wet.

Answer: C

QUESTION 20

A technician is troubleshooting a network connectivity issue on a MFD and would like to eliminate the possibility of another device on the network having the same IP address. The technician should:

- A. disconnect the MFD and ping the IP address.
- B. disconnect the MFD and ping the subnet mask.
- C. disconnect the MFD and ping the loopback address.
- D. run the ipconfig command from the command prompt.

Answer: A

Thank You for Trying Our Product

Lead2pass Certification Exam Features:

- ★ More than **99,900** Satisfied Customers Worldwide.
- ★ Average **99.9%** Success Rate.
- ★ **Free Update** to match latest and real exam scenarios.
- ★ **Instant Download** Access! No Setup required.
- ★ Questions & Answers are downloadable in **PDF** format and **VCE** test engine format.
- ★ Multi-Platform capabilities - **Windows, Laptop, Mac, Android, iPhone, iPod, iPad**.
- ★ **100%** Guaranteed Success or **100%** Money Back Guarantee.
- ★ **Fast**, helpful support **24x7**.



View list of all certification exams: <http://www.lead2pass.com/all-products.html>



Microsoft



ORACLE



CITRIX



JUNIPER
NETWORKS



EMC²
where information lives[®]

10% Discount Coupon Code: ASTR14